

To test a smoke detector~

- ✓ Press the battery test button on the detector to make sure the battery is properly connected.
- ✓ If the detector has a battery that is more than a year old, replace the battery (see information below).

- ✓ To replace a battery in a smoke detector:
 - ✓ Remove the smoke detector cover, typically be careful pulling down on the case's perimeter or by twisting the case counter-clockwise.
 - ✓ Locate and remove the battery. If needed, replace it with a new battery.
 - ✓ Close the case and test the smoke detector (see above).